

PLEASE READ
BEFORE MOUNTING!!
HOOD TO TRUCK

Thank you for purchasing a Jones Performance quality truck hood.
Please read the following information before installing your hood.

FIT BEFORE PAINTING

Lower Hood Snubber Bracket Mount Procedure

Due to inconsistant locations of the lower rubber snubber on the truck, we **have not** drilled the two holes for the lower hood snubber bracket.

Once the hood is installed and fit is acceptable, insert the lower hood snubber bracket on to the lower rubber snubber on truck. Clamp or hold the hood bracket in place to the inner fender. Drill and bolt to inner fender.

Tie Down Bracket

There are two different tie down bracket locations determined by year or cab. Because of this we have not drilled these holes. Once hood is installed and fit is acceptable, you will need to drill.

Side Emblem Holes

We have decided not to drill the side emblem holes as some customers do not use these emblems. We have marked the hood to assist in the location.

If you have any questions, suggestions or comments please contact us at 1-800-451-1600.