

PLEASE READ
BEFORE MOUNTING!!
HOOD TO TRUCK

Thank you for purchasing a Jones Performance quality truck hood.
Please read the following information before installing your hood.

FIT BEFORE PAINTING

THERE ARE 2 DIFFERENT STYLES OF 'U' NUTS ENLOCED FOR THE FOLLOWING AREAS: 11 FOR THE INNER FENDERS AND 10 FOR THE HEADLIGHTS.

REAR SNUBBER MOUNT PROCEDURE

YOU WILL NOTICE THIS AREA IS DIFFERENT FROM THE O.E. HOOD. WE HAVE REDESIGNED THIS AREA FOR GREATER STRENGTH AND DURABILITY. YOU WILL NOT NEED TO USE THE METAL SUPPORT FROM THE O.E. HOOD. BOLT THE RUBBER SNUBBER DIRECTLY TO THE JP REAR BRACE.

If you have any questions, suggestions or comments please contact us at
1-800-451-1600.