

PLEASE READ
BEFORE MOUNTING!!
HOOD TO TRUCK

THANK YOU FOR PURCHASING A JONES PERFORMANCE HOOD.

THIS IS A **ONE PIECE** HOOD MADE TO REPLACE YOUR 1997 AND UP 'O.E.' 3 PIECE SMC HOOD.

IMPROVED HINGE MOUNTS ARE INCLUDED. THESE HINGE MOUNTS HAVE BEEN MODIFIED TO ALLOW FOR EASY INSTALLATION OF HOOD. THE HINGE MOUNTS CAN NOT BE USED ON AN 'O.E.' HOOD.

FIT NOTE: DUE TO EXTENSIVE FIELD STUDIES ON THE FIT OF OUR HOOD, WE HAVE FOUND YOU MAY NEED TO ADD 'O.E.' SHIMS UNDER THE HINGE MOUNTS ON THE FRAME. THIS WILL RAISE THE FRONT OF THE HOOD AND ALLOW FOR AN EVEN COWL GAP. 'O.E.' HOODS ARE NORMALLY 3 - 4 SHIMS, WHILE YOUR 'JP' HOOD MAY REQUIRE 1 - 3 SHIMS MORE THAN THE 'O.E.' HOOD. 'KW' SHIM PART # 15027AA.

THE BOLT-ON INNER FENDERS ARE NOT REQUIRED ON YOUR 'JP' HOOD. THEY HAVE BEEN MOLDED INTO A ONE PIECE DESIGN WITH THE INNERSTRUCTURE. HOWEVER, YOU MAY WANT TO INSTALL THE RUBBER FLAPS: 'KW' PART # K213-3789.

INCLUDED IN THE ATTACHED PACKAGE:

- >INSULATION WASHERS FOR THE INSULATION TABS.
- >SELF-TAPPING SCREWS FOR THE 9 MOUNTS IN THE GRILL. THERE IS STEEL IN PLACE WHERE THE SCREWS WILL GO (SEE BELOW). HOLES SHOULD BE DRILLED WITH AN 11/64" BIT. MAKE SURE WHEN DRILLING YOU DO NOT GO THROUGH OUTER SHELL.

IF YOU HAVE ANY QUESTIONS OR COMMENTS YOUR FEEDBACK WOULD BE GREATLY APPRECIATED. PHONE: 1-800-451-1600.

