



1 Jones Way, P.O.Box 808, West Middlesex, PA 16159

(724) 528-3569 * Toll Free (800)-451-1600

jphoods@jonesperformance.com * www.trukrodz.com



TRUKRODZ™

READ BEFORE INSTALLATION

SPECIAL NOTE!

This is a Custom Hood so it **MUST** be fit before painting.

As always it is important to fit all hoods and all dress parts before painting. We feel with a Truk-Rodz custom hood, this is especially important to get proper clearance and to achieve that one of a kind unique look.

It is extremely important to fit first.

(PLEASE ADDRESS THE FOLLOWING FOR BEST FIT)

- Be sure that the cowl-opening gap is even top to bottom and Passenger side to Driver side.
- Verify that the fender to bumper line is an even gap.
- Test fit all dress parts and hardware.
- Road test to check for tire to wheel opening clearance. Trim if desired For a unique look.

Form #961

Date 4-30-08

App. CB

Rev. 2