

# ***HT Mounting Instructions***

***Model #PB335 Engine Model #C7***

***MFG Date 10/11/05***

***\*Please note bolts provided in brackets are for shipping purposes only! You must supply your own mounting bolts.***

***Front***

***1***



***Left*** → ***Right***

***Bolt mounting brackets to frame.***

***Side***

***2***



***Adjust angle of brackets for best fit.***

***Rear***

***3***



***Mount bumper to brackets.  
(Hand tighten only!)***

***Top***

***4***



***Attach factory mounting bracket  
to ear of bumper***

***Check all mounting points and adjust as nessary.  
Do not use impact wrench to tighten bolts on face of bumper!***

***800-354-0976 [www.valleychrome.com](http://www.valleychrome.com)***