Form 1013

BEFORE MOUNTING!!

Date: 2-10-11 Appr: 64 Rev.: 0

**HOOD TO TRUCK** 

Thank you for purchasing a Jones Performance quality truck hood. Please read the following information before installing your hood.

## **FIT BEFORE PAINTING**

THERE ARE 2 DIFFERENT STYLES OF 'U' NUTS ENLOCED FOR THE FOLLOWING AREAS: 11 FOR THE INNER FENDERS AND 10 FOR THE HEADLIGHTS.

If you have any questions, suggestions or comments please contact us at 1-800-451-1600.