

PLEASE READ

# BEFORE MOUNTING!!

FENDERS TO HOOD

**Thank you for purchasing a quality Jones Performance product.**

*Alert: Please fit fenders to center section before painting. Painting before fitting may void your fit warranty.*

We have included 1/4" stainless steel bolts and a roll of foam tape to attach your new fenders.

If installing front steps, be sure to verify fit at this time and drill the step mount holes in the front of fender using a 7/16" drill bit.

On 379 hoods, aftermarket front steps may need slight modifications to the step to fit the contour of the fender properly. Aftermarket rear steps will not fit.

We recommend to disassemble fenders at this time and painting center section and fenders separately. After painting, adhere the foam tape between fenders and center section before reinstalling fenders.

Although we have included the 1/4" stainless steel bolts to attach the fenders, you may also use hucks to attach the fenders to the center section.

If you have any questions, suggestions or comments please contact us at 1-800-451-1600.