

Date: 12-11-01

Appr.: GH Rev.: O

Jones Performance Products, Inc.

P.O. BOX 808 • 1 JONES WAY • WEST MIDDLESEX, PA 16159

## PLEASE READ BEFORE MOUNTING HOOD TO TRUCK

THE INFORMATION INSIDE PERTAINS TO THE VOLVO MODEL WCA NEW.

THANK YOU FOR PURCHASING A JONES PERFORMANCE HOOD.

THIS PROCEDURE IS TO HELP AID IN THE INSTALLATION OF THE INNER FENDERS AND THE INNER FENDER STABALIZERS.

\*WHEN BOLTING IN THE INNER FENDERS:

- START BY BOLTING UP TO THE 2 HOLES ON THE HINGE
- FOLLOW BY BOLTING UP THE 6 HOLES RUNNING ALONG THE INNER FENDER MOUNT.
- \*AFTER INSTALLING THE INNER FENDERS, ATTACH THE INNER FENDER STABALIZERS. THERE ARE 2 FOR THE DRIVER SIDE AND 1 FOR THE PASSENGER SIDE.
  - THE DRIVER AND PASSENGER SIDES BOTH HAVE A STABALIZER THAT BOLTS TO THE WING PLATE ON THE HINGE AND THEN TO THE INNER FENDER.
  - THE DRIVER SIDE HAS A SECOND STABALIZER THAT BOLTS TO THE REAR BRACE THEN TO THE INNER FENDER. THE HOLE TO USE ON THE REAR BRACE IS LOCATED JUST ABOVE THE 4 BOLT HOLES FOR THE SNUBBER BRACKETS.

IF YOU HAVE ANY QUESTIONS OR COMMENTS PLEASE CALL 1-800-451-1600. YOUR FEEDBACK WILL BE GREATLY APPRECIATED.