



Jones Performance Products, Inc.

P.O. BOX 808 • 1 JONES WAY • WEST MIDDLESEX, PA 16159

Date: 12-11-01
Appr.: GA
Rev.: 0

PLEASE READ BEFORE MOUNTING HOOD TO TRUCK

THE INFORMATION INSIDE PERTAINS TO
KW MODEL 900-A.

THANK YOU FOR PURCHASING A JONES PERFORMANCE HOOD.

THERE ARE INSULATION WASHERS ENCLOSED FOR THE
INSULATION TABS.

THE FOLLOWING INFORMATION IS IN REGARDS TO THE REAR
SNUBBER BRACKETS FOR YOUR HOOD.

YOUR J.P. HOOD HAS BEEN PREDRILLED TO ACCEPT THE KW
REAR SNUBBER BRACKET, PART # K273 - 180.

IF YOUR TRUCK WAS BUILT BEFORE 1978 YOU MAY HAVE A
DIFFERENT BRACKET. THIS BRACKET (PART # K273 - C - 117) IS NO
LONGER AVAILABLE FROM KW. THERE ARE TWO OPTIONS TO
PROPERLY FIT THIS HOOD TO YOUR TRUCK.

*OPTION #1: PURCHASE THE NEW STYLE BRACKETS, PART # K273 - 180.

*OPTION #2: BOLT YOUR OLD STYLE BRACKET TO THE REAR BRACE
BY USING THE CENTER HOLE IN THE BRACKET AND THE
CENTER HOLE OF THE 3 PREDRILLED HOLES IN THE
REAR BRACE. YOU WILL THEN NEED TO REDRILL THE
UPPER AND LOWER HOLES. THIS WILL NOT VOID YOUR
WARRANTY.

IF YOU HAVE ANY QUESTIONS OR COMMENTS YOUR FEEDBACK
WOULD BE GREATLY APPRECIATED: PHONE 1-800-451-1600.