

CY Mounting Instructions

2009 Freightliner Cascadia

****Please use the included bolts and hardware.***

Front

Frame View



Bolt mounting brackets to bottom of frame.

Adjust angle of brackets for best fit.

Top

Rear



Mount the top extension panels to bumper.



Attach provided mounting bracket to ear of bumper



Check all mounting points and adjust as necessary.

800-354-0976 www.valleychrome.com