

# Peterbilt 367 (HX) Setback

## Mounting Instructions

Step 1: Remove Factory Bumper



Step 2: Remove (& save) all mounting brackets



Factory brackets will be re-used for mounting new bumper

Step 3: Remove diamond plate for re-use



Step 4: Re-install all brackets onto bumper



Step 5: Once bumper is tightened, re-install diamond plate.