

PLEASE READ
BEFORE MOUNTING!!
HOOD TO TRUCK

Thank you for purchasing a Jones Performance quality truck hood.
Please read the following information before installing your hood.

FIT BEFORE PAINTING

Lower Hood Guide Blade Bracket Mount Procedure

Due to inconsistant locations of the lower bracket on the truck and with hood fit, we **have not** drilled the four 5/16" holes for the guide blade bracket.
(Part#A17-18757-000)

Once the hood is installed and fit is acceptable, insert the guide blade bracket into the bracket on the truck. Clamp or hold the guide blade bracket in place to the inner fender and drill the four 5/16" holes. Bolt in place using the back up plate and bolts provided.

Tie Down Bracket

There are two different tie down bracket locations determined by year or cab. Because of this, we have not drilled these holes. Once hood is installed and fit is acceptable, you will need to drill.

Side Emblem Holes

We have decided not to drill the side emblem holes as some customers do not use these emblems. We have marked the hood to assist in the location.

Included

We have included bolts and washers for the lower holes of the outer grille surround, wire harness hardware and lower hood guide blade bracket.

If you have any questions, suggestions or comments please contact us at 1-800-451-1600.